



Ingal Rub Rail - Data Sheet

Improving Motorcycle Safety

Specification

- Ingal Rub Rail is designed for attachment to G4 W Beam or Type B Guardfence
- Ingal Rub Rail protects motorcyclists from impacting guardrail posts
- No dismantling of the existing guardrail system required for Ingal Rub Rail attachment
- Hot dipped galvanized in accordance with AS/NZS 4680:1999
- No aggressive edges or corners
- Straight sections of Ingal Rub Rail can be field curved to a radius of 20m





Installation of Ingal Rub Rail

Ingal Rub Rail can be installed on existing guardrail with posts at 2m or 2.5m.

Typical installation sequence as follows;

- 1. Loosen the M16x50mm post bolt/nut that currently secures the guardrail panel to the blocking piece.
- Slide the Ingal Rub Rail mounting bracket between the blocking piece and the guardrail panel ensuring the post bolt has engaged the middle slot located in the mounting bracket.
- 3. After positioning the mounting bracket, retighten the bolt.
- 4. Mount the Ingal Rub Rail against the mounting bracket and secure using a M16x32mm mushroom head bolt. Ensure the rub rail lap is orientated with no leading edges towards the traffic face.
- 5. Join the rub rails together using M16x32mm mushroom head bolts.
- Brisbane (07) 3271 3369 Melbourne (03) 8470 0082
- Perth (08) 9249 3155 Sydney (02) 9827 3333 Adelaide (08) 8169 2300
- Newcastle 0400 235 883 Orange 0427 779 588

